



berner

FFP3 Sterile Respiratory Facemask

A single-use, respirator half mask designed to provide the highest level of particle protection against solid and liquid particles in controlled work applications.

The folding cup-shape design ensures a secure and comfortable fit with any face shape. Easily adjustable elasticated straps with soft internal sealing lips provide a tight-fit, complementing the facemasks protective function. An integrated exhalation valve grants minimal respiratory resistance, making this mask comfortable to wear for longer time periods.

Each facemask is presented individually polybagged and pre-sterilised, ideal for immediate transfer and use in cleanroom environments.

Features and Benefits

- ✓ High level particle protection
- ✓ Adjustable to fit any face shape
- ✓ Comfortable and entirely latex-free
- ✓ PFE > 99%*
- ✓ Pre-sterilised for cleanroom applications
- ✓ Integrated exhalation valve for easy breathing
- ✓ Tested and certified to EN 149:2001+A1:2009

*PFE – Particle Filtration Efficiency

Ordering Information

FM121286

Berner FFP3 Sterile Respiratory Facemask
sterile • 4 pcs/pck



FM121286



Technical Data

Material	Headband	Textile headband made of polyurethane fibre
	Filter/ mask	Polypropylene, polyester
	Sealing lip	Polyethylene foam
	Valve	Polystyrol
Colour	Grey with white strap	
Properties	Latex-free	
Fitting	Threaded elasticated strap	
Material Weight	18g	
Packaging	Individually polybagged; 4 x facemasks per pack	
Test Performance Per ASTM F2100	Filtration efficiency (minimum) (PFE) – sodium chloride > 99%, paraffin oil > 99% Passed dolomite clogging test for FFP-3 mask (dolomite DRB4/15b test aerosol)	
Compliance	Certified in accordance with the standard EN 149:2001 + A1:2009; CE mark for complex PPE in Category III in accordance with PPE Directive 89/686/EEC; it does not provide protection against gases and vapours	
Sterilisation	Sterilised by Ethylene Oxide (ETO)	
Shelf Life	3 years from date of manufacture	

