

Sealed Foam Swabs Test Data

| Head Material | Sealed Urethane Foam | | |
|-------------------------------|----------------------|--------------------|-------------------|
| Swabs: | 41050 | 41050I | 48040 |
| Head Diameter | 0.14" (3.56 mm) | 0.14" (3.56 mm) | 0.12" (3.0 mm) |
| Handle Length | 2.80" (7.2 cm) | 2.80" (7.2 cm) | 2.75" (7.0 cm) |
| Particle Counts: | | | |
| 0.5 - 1 um | 571 | 485 | 797 |
| 1.0 - 2 um | 96 | 63 | 230 |
| 2.0 - 5 um | 37 | 18 | 66 |
| 5.0 - 10 um | 31 | 13 | 24 |
| 10 - 25 um | 19 | 8 | 11 |
| over 25 um | 9 | 1 | 2 |
| TOTAL | 762 | 586 | 1,130 |
| NVR (ug/swab) | none detected | none detected | none detected |
| Chlorides (ug/swab) | none detected | none detected | none detected |

The swabs were tested by Particle Measurement Technology. All tests were done using the recommended practices of the Institute of Environmental Science, Swabs and Wipes Working Group.