

STOP PRESS ** STOP PRESS **** STOP PRESS**

Company: Helapet Ltd

Contact: Ruth Hewitt – 01582 501983

Date: 14th January 2010

Title: Use SteriClean Neutral Detergent for maximum cleaning

SteriClean Neutral Detergent is now available to complement the SteriClean range of broad spectrum Biocidal and alcohol disinfectants.

A detergent with a PH7 +/- must be used in critical applications where surfaces could be damaged by acid or alkaline solutions. SteriClean neutral detergent is an ideal choice for aseptic areas and pharmaceutical cleanrooms where soiling needs to be removed prior to cleaning with an active biocidal agent.

SteriClean neutral detergent is blended with ionised water, filtered to 0.2 micron and filled in a class 10,000 cleanroom. Ready mixed and validated for maximum effect, each 0.9 litre bottle is supplied individually double bagged and sterilised by gamma irradiation at no less than 25 kGy.

The combined effect of the non-venting trigger and the bag in a bottle closed system, ensures the sterility of the contents throughout use and independent validation data has demonstrated that the sprays remain sterile for up to three months from opening.

For more information and to try SteriClean cleaning in your unit, please call our sales team on 0800 0328 428 or visit our website www.helapet.co.uk

210 words

Ends